



Set up instructions for Quick Snap & Quick Snap/Foam Berms

The deployment of the Quick Snap or Quick Snap/Foam Berm can be completed by one or two people.

- 1) Locate a level area to deploy the berm and clear it of any debris that may cause damage to the berm.
- 2) Place the Ground Pad (optional) in the center of the cleared area and unfold.
- 3) Place berm in the center of the deployment area and unfold the berm.
- 4) Remove elastic from Quick Snap Stay, lift berm wall and snap stay together. Repeat procedure for remaining stays.

(For Quick Snap Berm set up skip to Step 6.)

- 5) Install the foam logs into the pockets of berm. Secure berm logs together using the included zip ties. (Berm logs will still function properly without being zip tied together.)
- 6) Place the Track Mat (optional) in the berm.
- 7) Secure the perimeter of the berm using the staking points provided. If the berm is being deployed on a hard surface sand bags or weights can be placed around the berm skirt.

Thank you for choosing AIRE Industrial.